

Gebrauchs- und Pflegeanleitung: PAB® Pad



Lesen Sie die folgenden Sicherheitshinweise und benutzen Sie den Artikel nur wie beschrieben, damit es nicht zu Verletzungen und Schäden kommt. Bewahren Sie diese Anleitung zum späteren Nachlesen auf. Geben Sie die Anleitung auch bei Weitergabe des Artikels unbedingt mit.

Herzlichen Glückwunsch zum Kauf Ihres neuen PAB® Pad.

Mit dem PAB® Pad haben Sie sich für ein TOGU® Markenprodukt „made in Germany“ entschieden!

Die platzsparende Alternative zum großen Ball mit neuartiger Gel-Füllung. Als reaktiv-dynamische Unterlage und Gewichtsscheibe einsetzbar nach dem „Power and Balance“ PAB® Konzept, für Rückentraining und Gymnastik sowie für koordinative und sensomotorische Übungen.

Ausstattung:

Beide Seiten mit samtig glatter Oberfläche: PAB® Pad

Das PAB® Pad ist mit einem wasserbasiertem Gel gefüllt. Die Aussen-Hülle ist aus hochwertigem Ruton® hergestellt.

Durchmesser: ca. 36 cm

Belastbarkeit: max. 300 kg

Temperatur-Beständigkeit:

Das PAB® Pad ist UV-beständig und auch bedingt hitzebeständig. Bis 45°C kann das PAB® Pad problemlos eingesetzt werden. Es sollte jedoch nicht bei direkter Sonneneinstrahlung gelagert werden (z.B. am Fenster). Das Material wird durch zunehmende Wärme weicher.

Das PAB® Pad ist auch kältebeständig, jedoch sollte die Lagerungstemperatur nicht unter -10°C liegen. Das Material wird durch zunehmende Kälte fester.

Pflege:

Zum Reinigen des PAB® Pad können Sie alle milden, handelsüblichen Reinigungs- sowie Desinfektionsmittel verwenden. Lösungsmittelhaltige, säurehaltige oder ätzende Reiniger greifen das Material an. Das PAB® Pad ist wasserfest.

Lagerung:

Bitte lagern Sie ihr PAB® Pad immer flach liegend.



ACHTUNG!

Wichtige Sicherheitshinweise:

- Das Produkt ist nicht für Kleinkinder geeignet! Kein Spielzeug!
- Der Verschlussstöpsel darf nicht entfernt werden.
- Das Gerät darf nicht von Kindern unter 3 Jahren benutzt werden. Kinder über 3 Jahre dürfen es nur unter Aufsicht nutzen.
- Halten Sie das Gerät fern von scharfen oder spitzen Gegenständen, um Schäden am Gerät zu vermeiden.
- Undichte/beschädigte Geräte dürfen nicht mehr verwendet werden. Sie können das Gerät in diesem Fall über uns dem Recyclingprozess zuführen.
- Der Produktinhalt ist nicht zum Verzehr bestimmt.

Instructions for use and care: PAB® Pad



Please read the following safety instructions and only use the product as described to avoid injury and damage. Keep these instructions for future reference. Be sure to include the instructions when passing the product on to someone else.

Congratulations on purchasing your new PAB® Pad.

With the PAB® Pad, you have chosen a TOGU® brand product “**made in Germany**”!

The space-saving alternative to the large ball with innovative gel filling. Can be used as a reactive-dynamic base and weight disc according to the “Power and Balance” PAB® concept, for back training and gymnastics as well as for coordination and sensorimotor exercises.

Features:

Both sides with a velvety smooth surface: PAB® Pad

The PAB® Pad is filled with a water-based gel. The outer cover is made of high-quality Ruton®.

Diameter: approx. 36 cm

Load capacity: max. 300 kg

Temperature resistance:

The PAB® Pad is UV-resistant and also heat-resistant to a certain extent. The PAB® Pad can be used without any problems at temperatures up to 45°C. However, it should not be stored in direct sunlight (e.g., on a window sill). The material becomes softer as the temperature rises.

The PAB® Pad is also cold-resistant, but the storage temperature should not fall below -10°C. The material becomes harder as the temperature drops.

Care:

You can use any mild, commercially available cleaning agent or disinfectant to clean the PAB® Pad. Solvent-based, acidic, or corrosive cleaners will damage the material. The PAB® Pad is waterproof.

Storage:

Please always store your PAB® Pad flat.



ATTENTION!

Important safety information:

- The product is not suitable for small children! It is not a toy!
- The sealing plug must not be removed.
- The device must not be used by children under 3 years of age. Children over 3 years of age may only use it under supervision.
- Keep the device away from sharp or pointed objects to avoid damage to the device.
- Leaky/damaged devices must no longer be used. In this case, you can send the device to us for recycling.
- The product contents are not intended for consumption.